



Versandanschrift
 Address
 Adresse du destinataire
 Indirizzo di trasporto
 Dirección de expedición

Fax.-No

Ersatzteilliste
 Spare parts list
 Liste des pièces de rechange
 Elenco parti di ricambio
 Lista de piezas de repuesto

945474	TruTool S 160 (1A1)	230V 50/60Hz D
947986		230V 50/60Hz CH
947987		110V 50Hz GB
947988		120V 50/60Hz USA
947989		230V 50/60Hz PL
947990		220V 60Hz KR

NO. D'ORDINE NO. DE REF. NO. DE REF. ORDER. NO. NO	BEST.-NR.	PEZZO DI RICAMBIO PIEZA DE RECAMBIO PIECE DE RECHANGE SPARE PART ERSATZTEIL	DIN	QUAN. CANT. QUAN. QUAN. STK.
1	014559	M5x18	DIN 912	
2	945476			
3	027669		DIN 625	
4	119584	Ø 8x20 / 0.5	DIN 988	
5	119583	RSTO 8	DIN 620	
6	122906	Ø 12x24 / 0.5	DIN 988	
7	119301			
8	941013			
9	143456			
10	085928	Ø 5.1x11 / 0.8		

11	027693		DIN 625	
12	941019			
13	014400	M4x8	DIN 912	
14	941016	0,2		
	941017	0,4		
	941018	0,6		
15	941014	+Pos. 14		
16	015164	M10x20	DIN 912	
17	044502	Standard		
	919760	„Cr“		
18	087705	M4x8	DIN 913	
19	087704	M5x10	DIN 7500	
20	947556			
21	950632	Pos. 4,8,9		

