



Versandanschrift  
 Address  
 Adresse du destinataire  
 Indirizzo di trasporto  
 Dirección de expedición

Fax.-No

Ersatzteilliste  
 Spare parts list  
 Liste des pièces de rechange  
 Elenco parti di ricambio  
 Lista de piezas de repuesto

<b>1378586</b>	<b>D 230V 50/60Hz</b>
<b>1378589</b>	<b>CH 230V 50/60Hz</b>
<b>1378690</b>	<b>GB 110V 50Hz</b>
<b>1378594</b>	<b>USA 120V 50/60Hz</b>
<b>1378691</b>	<b>KR 220V 60Hz</b>

**TruTool**  
**S 114 (1A1)**

NO.	D'ORDINE	PEZZO DI RICAMBIO	QUAN.
NO.	DE REF.	PIEZA DE RECAMBIO	CANT.
NO.	DE REF.	PIECE DE RECHANGE	QUAN.
ORDER. NO.	SPARE PART	QUAN.	
NO	BEST.-NR.	ERSATZTEIL	DIN
			STK.
1	0143458		
2	0133609	8-FDST	DIN 7993
3	0143460		
4	1376494	(2x)	
5	1381891		
6	1381892		
7	0071605	4m6x18-A-ST	ISO 8734
8	1375550		
9	1375552		
10	0014559	M5x18	ISO 4762
11	0350327		
12	0358451		
13	0756427		
14	0143461		

15	0014591	M5x30	ISO 4762
16	0143453		
17	0143457		
18	0143456		
19	0100846	7x13x0,2	DIN 988
20	0143422	RSTO 6XTN	DIN 620
21	0917552	10x16x1,5	DIN 988
22	0027693	625	DIN 625
70	0342315	230V D 50/60Hz	
	0342316	230V CH 50/60Hz	
	0342861	110V GB 50Hz	
	1299614	120V USA 50/60Hz	
	0342315	220V KR 60Hz	
71	1378597	230V D 50/60Hz	
	1378597	230V CH 50/60Hz	
	1378693	110V GB 50Hz	
	1378599	120V USA 50/60Hz	
	1378694	220V KR 60Hz	
72	0143643		

