


# UNI 4 Motor Assembly & Parts List



Nr.	Description	Qty	Part No.
1	Armature 240V	1	EIB357
1	Armature 110V	1	EIB357-1
2	Uni3/4 Armature Bearing Cap	1	EIB194
3	Field Coil 240V	1	EIB360-2
3	Field Coil 110V	1	EIB360-1
4	Fan cover	1	EIB362
5	Motor Housing	1	EIB019
6	Brush Holder	2	EIB036
7	Carbon Brush	2	EIB047
8	Screw HC 2,9x13	4	EIB196
9	Brush Cover	2	EIB020
10	Screw HC 4,2x13	2	EIB154
11	Spring Washer S6	2	EIB197
12	Screw HC 4,2x25	2	EIB155
13	Capacitor	1	EIB139
14	Drill Cap	1	EIB364
15	Screw HC 4,8x50	4	EIB157
17	Gear Box Housing	1	EIB365
18	Gear Change Assembly	2	EIB017
19	Gear Plate Shield	1	EIB366
20	Gear Box Gasket	1	EIB367
21	Screw 4,5x50	4	EIB368
22	Gear Plate	1	EIB369
23	Gear Lever	1	EIB370
24	Gear Lever	1	EIB371
25	Screw M5x2,5	4	EIB372
26	M5 Spring Washer	4	EIB082
27	Needle Bearing RNA 4900	1	EIB162
28	Washer	1	EIB163
29	Bearing "6201 2RS	1	UDC024
30	Circlip 32/1,2	1	EIB043
31	Circlip11,1	1	EIB143
33	Circlip 55/2	1	EIB374
34	Washer	1	EIB375
35	Bearing 6006 2RS	1	UDC007
36	Bearing 6000	2	UDC001
37	Needle Bearing HK 0810	3	UDC020
38	Clutch Gear assembly	1	EIB373
39	Trailer Gear	1	EIB378
40	Fitting Key 5x5x10	1	EIB146
41	Clutch Gear - Worm Drive (standard)	1	EIB060
41	Clutch Gear - Straight Drive (FR only)	1	EIB060-A
42	Clutch Coupling	1	EIB015
43	Washer 28/12,2x1	4	EIB147
44	Thrust Washer	1	EIB379
45	Washer 12/18x2,0	1	EIB148
46	Circlip 9	1	EIB149
47	Trailer Gear	1	EIB380
48	Fitting Key A5x5x28	1	EIB034
50	Gear Block	1	EIB381
51	Trailer Gear	1	EIB382
52	Fitting Key A6x6x40	1	EIB383
53	Gear Block	1	EIB384
54	Circlip 47/1,75	1	EIB385
55	Bearing 6005 2RS	1	UDC005
56	Compressor Ring 25x0,1	1	EIB165
57	Main Gear	1	EIB016
58	Circlip 24/1,2	1	EIB041
59	Thrust Washer	1	EIB386
60	Locating Dowell 5x16	1	EIB387
61	Spindle	1	EIB388
62	Key B6x6x20	1	EIB164
63	Eibenstock Cable Clip	1	EIB085
64	Screw HC 4,2x19	1	EIB359